

CARTRIDGE REPLACEMENT SCHEDULE

Keep Your BOTANVÈ Filter Performing at Its Best

THE GENERAL RULE

Replace your BOTANVÈ filter cartridge every **3 months**, or after approximately **10,000 litres** of throughput — whichever happens first. Filtration performance declines gradually as the KDF and carbon media reach saturation, so replacing on a fixed schedule (rather than waiting for a visible change in water) is the only reliable way to guarantee continued performance.

Standard replacement interval	Every 3 months (90 days)
Throughput-based limit	10,000 litres, whichever comes first
Typical household (2–3 people)	3-month interval usually applies
Heavy-use household (4+ people / daily long showers)	Consider 2–2.5 month interval
Compatible cartridges	BOTANVÈ Genuine Replacement Cartridge — fits all current shower head and handheld models

ESTIMATING YOUR LITRE USAGE

Based on an average flow-restricted rate of approx. 12 litres/minute through the BOTANVÈ unit. Use this as a planning guide — actual flow varies with your home's water pressure.

Household profile	Daily use	Monthly volume	Est. cartridge life
1 person, 1 shower/day (~8 min)	~96 L/day	~2,880 L/month	~3.5 months per cartridge
2 people, 1 shower/day each	~192 L/day	~5,760 L/month	~1.7 months per cartridge
3–4 people, 1 shower/day each	~320–380 L/day	~9,600–11,400 L/month	~1 month per cartridge
1 person, every other day	~48 L/day avg	~1,440 L/month	~7 months (cap at 3 months)

Important: even where litre-based estimates suggest a longer interval, BOTANVÈ still recommends a hard cap of 3 months per cartridge, since carbon media can lose effectiveness over time even at lower throughput.

YOUR PERSONAL REPLACEMENT TRACKER

Write your installation date below, then mark your next 4 replacement dates at 3-month intervals. Set a reminder on your phone for each date — or subscribe to BOTANVÈ auto-replenishment so a new cartridge arrives automatically before each due date.

Milestone	Date (DD/MM/YYYY)	Status
Installed	____ / ____ / ____	■ New install
Replacement 1	____ / ____ / ____	■ Done ■ Reminder set
Replacement 2	____ / ____ / ____	■ Done ■ Reminder set
Replacement 3	____ / ____ / ____	■ Done ■ Reminder set
Replacement 4	____ / ____ / ____	■ Done ■ Reminder set

SIGNS YOUR CARTRIDGE NEEDS CHANGING SOONER

- Noticeable drop in water flow/pressure through the shower head.
- Return of a chlorine smell or taste in the shower water.
- Visible discolouration or sediment building up at the outlet face.
- It has been 3 months since your last cartridge swap, regardless of the above.

HOW TO REPLACE A CARTRIDGE

1. Turn off the water supply. 2. Unscrew the filter housing cap counter-clockwise by hand. 3. Remove the spent cartridge and dispose of it (cartridges are not designed to be cleaned or reused). 4. Insert the new genuine BOTANVÈ cartridge, ensuring the sealing O-ring is seated. 5. Screw the housing cap back on hand-tight. 6. Turn the water back on and flush for 30–60 seconds before use. No tools are required and the process takes under 5 minutes.

ORDERING REPLACEMENTS

Genuine BOTANVÈ cartridges are available as single, twin and 4-pack options on botanve.co and via our Amazon.ae storefront. Stocking a 4-pack covers a full year of standard 3-month replacements. Only genuine BOTANVÈ cartridges are warranted to deliver the filtration specifications described in the Technical Filtration Guide — third-party or generic cartridges may not seal or perform correctly and can void your product warranty.